



H510 Offset Bracket Quick Setup Guide

This Quick Setup Guide provides instructions on how to install the H510 AP using the optional offset bracket. The H510 Offset Bracket (part #902-0126-0000) is designed to offset the H510 from a wall that does not have an in-wall cable routing box.

PACKAGE CONTENTS

Verify that all items listed below are included in the package. If any item is damaged or missing, notify your authorized Ruckus Wireless sales representative.

- One H510 offset bracket
- Two torx mounting screws
- This *Quick Setup Guide*


REQUIRED HARDWARE AND TOOLS

- One Ruckus Wireless H510 wall switch AP
- T8 Torx driver
- Customer-supplied mounting screws and plastic wall anchors
- An electric drill with drill bits
- Screwdriver with assorted bits

MOUNTING THE AP WITH OFFSET BRACKET


- 1 Use the accessory bracket as a template to mark the locations for drill holes (four mounting hole locations).

Figure 1 Offset bracket mounting holes




- 2 Drill holes of the appropriate size for the customer-supplied mounting screws and plastic wall anchors.
- 3 If you will be running the uplink Ethernet cable through the bottom of the offset bracket, remove one of the punch-out tabs at the bottom of the offset bracket.
- 4 Attach the bracket to the wall using the plastic wall anchors and mounting screws.
- 5 Run the Ethernet uplink cable through the punch-out tab opening in the bottom of the offset bracket (or through the large hole in the center of the offset bracket).
- 6 Remove the two torx screws from the sides of the H510.

Figure 2 Remove torx screws from AP




- 7 Remove the flat mounting bracket from the back of the AP. This bracket will not be used when using the offset bracket.

Figure 3 Remove flat bracket from rear of AP



- 8 Connect the uplink cable to the AP's LAN 5/PoE In port.
- 9 The offset bracket has two lower hooks that fit into slots on the bottom of the H510. Rest the bottom of the H510 on the hooks.
- 10 Tilt the H510 toward the wall until it is up against the offset bracket.

Figure 4 Mount the H510 to the offset bracket



- 11 Insert the two torx screws from the bracket kit into the sides of the AP to lock the AP to the bracket.

Congratulations! You have completed mounting the H510 using the offset bracket mounting kit.